

[NIKO BALL BEARINGS & TAPER ROLLER BEARINGS &
SPHERICAL ROLLER BEARINGS BOX PACKING METHOD]



Inner bore $\geq 90\text{mm}$, use NIKO Ply-wood
boxes packing.

For example,
NIKO 6018 ZZ

PAGES

6~8

Concerning the model number without remark(OEM1), Inner bore ≥ 90 mm,
use NIKO Ply-wood boxes packing../ 1x1 packing,
please refer to (A)-(E)

For example,
NIKO **6018 ZZ** it means 1x1 individual small box packing.

PACKING METHOD: 1 x 1

(A): Put the bearing into the suitable small plastic bag;



(B): Paste the model label on the small box;



(C): Put it into the suitable small box according to step one;



(D): Paste tape for small box, individual small box packing finished;



(E): Put the individual small boxes packing into the NIKO Ply-wood boxes ;



Final packing effect is finished;

